



SURFACES PREPARATION

TECHNICAL INFORMATION

COVERAGE 14-17 m²/liter / coat

APPLICATION Brush / Roller / Spray Gun

THINNER White Spray

DRYING TIME 12 hours between coats

NO OF COATS 2-3

THINNING By Roller / Brush 10-50%
By Spray 25%

CLEANING Clean all equipment with Spirit
or Turpentine

Surface must be clean, dry and free from all surface contamination. Treat mould with bleach then rinse with clean water. Fill in surface defects with a suitable filler or sealant and sand smooth.

REPAINT

Remove all loose and flaking paint and sand glossy or enamel surfaces thoroughly with 200 grit. Prepare bare areas as for new work. Wash to remove dirt and chalk. Apply one coat of an oil-based undercoat (e.g. WallmanUndercoat or Red Oxide Primer)

APPLICATION

Confirm colour before use. Carefully apply two liberal coats of Wallman Matt Enamel by brush or roller. A 7mm mohair roller cover or similar will give best results. Excess film thickness will result in runs and slow drying. Avoid painting late in the afternoon as condensation may affect drying and gloss.

- Stir paint in a circular lifting motion for 5 minutes before use
- Drying time: 4 hours (touch dry)
- Recoat: 16 hours at 25°C (in cold, damp, or humid conditions, drying time may be lengthened)
- Do not paint at temperatures below 10°C
- More than one can of the same colour and product is required, mix the contents of all the cans together to ensure colour consistency.



Extreme Durability



Flexible Paint Film



Long Lasting Protection



UV Resistant



Quick Drying



Breathable



Water Based
Low Odour



Stain Resistant



Antimicrobial

PREPARATION REQUIRED

- New surfaces.
- Previously painted surfaces.
- Powdery dusty surfaces.
(With cracks and other surface defects)

FINISH



SUPERIOR

SMOOTH

NORMAL

LOW

✓ SMOOTH